



# Quick Start Reference Guide \*

## Parts & Assembly



**IMPORTANT:** Your Power Cooker™ has been shipped with the components shown above. Check everything carefully before use. If any part is missing or damaged do not use this product and contact shipper using the customer service number located in the back of the owner's manual.

\*This Guide is not a substitute for the Owner's Manual. Refer to this guide only after you have read the Owner's Manual thoroughly.

## Step 1

Place Inner Pot into the unit with food. Never load Inner Pot above the MAX line. Rotate the Inner Pot to make certain that it is seated properly on the Heating Plate.

Check for proper placement of Rubber Gasket/Lid Liner (underside Lid rim) then, place Cooker Lid on Cooker with Lid Handle and Pressure Valve pointed to the "1:00 O'clock" position (fig. A). Rotate Lid counterclockwise until you feel a click and the symbols on the Lid are centered with the LED Display.



## Step 2

Before cooking, make certain that the Rapid Release Button is in the Closed position (fig. B) and the Pressure Valve is free floating and clear of any obstructions. Attach the AC Cord to the base of the unit then plug the AC Cord into a dedicated 120V wall outlet.

You may now program the unit for cooking using the Control Panel and the Owner's Manual as a guide. The cooking time "count down" begins when desired Pressure Setting is reached (about 17 minutes).

**Please Note:** When the unit is first plugged in, 0000 will appear on the LED Display. When a cooking process is selected, such as COOK, the default time will blink 5 times. Then rotating double zeros may appear on the left side of the screen to signify it is building pressure. Once pressure is built, the zeros will stop rotating and begin counting down the time. It will beep, the LED Display will be blank, and enter KEEP WARM mode once the time has expired until cancelled.



## Step 3

Steam and Pressure must be released completely from the Cooker before the Lid will open. To do this, carefully slide the Rapid Release Button forward (fig. C) in short bursts at first. After initial short bursts, leave the button in the forward position until all pressure has escaped and the digital pressure indicator does not register. **Caution:** During this process protect your skin from any contact with escaping steam. Press down gently on Lid and turn clockwise until Lid meets resistance... lift carefully and place aside. Avoid personal injury resulting from hot unit surfaces and dripping liquids. Press Cancel and unplug cooker from AC outlet.

